



Overview of WPC / GV-7i system components and accessoires

- AUTO start** Used for automatically starting the generator
- WPCbus** Used for WPC communication
- DDCbus** Used for Generator communication

